

## HOT TUB & SWIM SPA START UP

Once the electrical has been connected

1. Fill the tub by removing the filters and inserting the garden hose into the filter basket. The recommended fill level is indicated on your filter basket. Or fill water level up to 1 inch below the bottom of the Headrests DO NOT OVER FILL YOUR TUB ( it could void warranty )
2. Switch on the breaker at the panel inside the house and the switch on the GFCI switch.

The tub will turn on itself and run a diagnostic. You will see a message on the screen that says "RUN PUMPS-PURGE AIR" Press JETS 1 & JETS 2 to prime the pumps and purge the air from the lines. Leave pumps running.

3. Once the spa has run one full cycle and the heat light is on solid, insert the filters back into the tub, submerge them under the water first letting as much air out from them before screwing them back in. Place them back into the filter area very slowly and screw them in.
4. Wait approx 8 hrs for your spa to heat, check the control panel and use the UP or DOWN arrows to set desired temp.
5. Once the temp has reached at least 95 degrees - For first time use add the following into the water:
  - HOT TUBS - Add 1 Large Cap of FUSION
  - SWIM SPAS - Add 3 Large Caps of FUSION

Start to use your hot tub and follow the GENERAL CHEMICAL INSTRUCTIONS SHEET available online under the OWNERS Section.

## **BLUETOOTH SOUND SYSTEM CODE - 2288**

**\*\* If you suspect there to be anything wrong with your spa or swim spa or if it is not operating properly, please do the following:**

**Visit [www.glacierspas.ca](http://www.glacierspas.ca) – Click the SERVICE link & fill out service request form and/or live chat with a specialist online.**

**DO NOT CALL YOUR SALES PERSON FOR SERVICE**

**FOR ASSISTANCE PLEASE USE THE ONLINE CHAT @  
GLACIERSPAS.CA**